

SMOKE DETECTION PANEL XL No.8 SCHEDULE 'A' (SINGLE ADDRESS INPUTS)

INPUT		OUTPUT		
ADDRESS	INITIATING DEVICES	ANNUNCIATOR MESSAGES	ACTIVATED RELAYS	ACTIVATED HVAC EQUIPMENT
081101	AREA SMOKE DETECTOR	E-7-18 AREA ALARM TWR 2	POX-29-112	E-7-18 SHUTDOWN
081102	AREA SMOKE DETECTOR	ACS-7-11 AREA ALARM	POX-21-034	ACS-7-11
081103	DUCT SMOKE DETECTOR	ACS-7-11 DUCT ALARM		
081104	DUCT SMOKE DETECTOR	ACS-7-3 AREA ALARM	POX-19-014	ACS-7-3
081105	AREA SMOKE DETECTOR	ACS-7-3 DUCT ALARM		
081106	DUCT SMOKE DETECTOR	ACS-7-8 AREA ALARM	POX-21-031	ACS-7-8
081107	AREA SMOKE DETECTOR	ACS-7-8 DUCT ALARM		
081108	DUCT SMOKE DETECTOR	ACS-7-10 DUCT ALARM	POX-26-082	ACR-7-10
081109	DUCT SMOKE DETECTOR	ACR-7-10 DUCT ALARM	POX-21-034	ACS-7-11
081110	DUCT SMOKE DETECTOR	ACR-7-8 DUCT ALARM	GROUP A	GROUP A
081111	DUCT SMOKE DETECTOR	ACR-7-7 DUCT ALARM		
081112	DUCT SMOKE DETECTOR	E-7-21 DUCT ALARM	POX-30-121	E-7-21
081113	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 9 SE		
081114	AREA SMOKE DETECTOR	SMOKE IN SUB 7E	SPX-13-014	ALARM STATIONS
081115	AREA SMOKE DETECTOR			
081116	AREA SMOKE DETECTOR	PULL STATION IN SUB 7E		
081117	MANUAL PULL STATION			
081118	MANUAL PULL STATION			
081119	MANUAL PULL STATION			
081201	AREA SMOKE DETECTOR	ACS-7-10 AREA ALARM TWR 2	POX-21-033	ACS-7-10 SHUTDOWN
081202	DUCT SMOKE DETECTOR	ACS-7-10 DUCT ALARM		
081203	AREA SMOKE DETECTOR	ACS-7-2 AREA ALARM	POX-19-013	ACS-7-2
081204	DUCT SMOKE DETECTOR	ACS-7-2 DUCT ALARM		
081205	AREA SMOKE DETECTOR	ACS-7-7 AREA ALARM	POX-20-024	ACS-7-7
081206	DUCT SMOKE DETECTOR	ACS-7-7 DUCT ALARM		
081207	DUCT SMOKE DETECTOR	ACS-7-12 AREA ALARM	POX-22-041	ACS-7-12
081208	AREA SMOKE DETECTOR	ACS-7-12 DUCT ALARM		
081209	DUCT SMOKE DETECTOR	ACR-7-6 DUCT ALARM	GROUP A	GROUP A
081210	DUCT SMOKE DETECTOR	ACR-7-5 DUCT ALARM		
081211	DUCT SMOKE DETECTOR	ACR-7-11 DUCT ALARM	POX-26-083	ACR-7-11
081212	DUCT SMOKE DETECTOR		POX-22-041	ACS-7-12
081213	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 9 NE	GROUP A POX-25-071 POX-25-072 POX-25-073 POX-25-074 POX-19-013 POX-19-014 POX-20-024 POX-21-031 POX-21-033	ACR-7-5 SHUTDOWN ACR-7-6 ACR-7-7 ACR-7-8 ACS-7-2 ACS-7-3 ACS-7-7 ACS-7-8 ACS-7-10
081301	AREA SMOKE DETECTOR	ACS-7-13 AREA ALARM TWR 2		
081302	DUCT SMOKE DETECTOR	ACS-7-13 DUCT ALARM		
081303	AREA SMOKE DETECTOR	ACS-7-5 AREA ALARM		
081304	DUCT SMOKE DETECTOR	ACS-7-5 DUCT ALARM		
081305	AREA SMOKE DETECTOR	ACS-7-4 AREA ALARM		
081306	DUCT SMOKE DETECTOR	ACS-7-4 DUCT ALARM		
081307	AREA SMOKE DETECTOR	ACS-7-9 AREA ALARM		
081308	DUCT SMOKE DETECTOR	ACS-7-9 DUCT ALARM		
081309	DUCT SMOKE DETECTOR	ACR-7-12 DUCT ALARM		
081310	DUCT SMOKE DETECTOR	ACR-7-1 DUCT ALARM	GROUP B	GROUP B
081311	DUCT SMOKE DETECTOR	ACR-7-2 DUCT ALARM		
081312	DUCT SMOKE DETECTOR	ACR-7-9 DUCT ALARM	POX-26-081	ACR-7-9
081313	DUCT SMOKE DETECTOR	E-7-20 DUCT ALARM	POX-29-114	E-7-20
081314	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 9 SW		
081315	AREA SMOKE DETECTOR	SMOKE IN SUB 7W	SPX-14-024	ALARM STATIONS
081316	AREA SMOKE DETECTOR			
081317	AREA SMOKE DETECTOR	PULL STATION IN SUB 7W		
081318	MANUAL PULL STATION			
081319	MANUAL PULL STATION			
081320	MANUAL PULL STATION			
081401	AREA SMOKE DETECTOR	ACS-7-6 AREA ALARM TWR 2	POX-20-023	ACS-7-6 SHUTDOWN
081402	DUCT SMOKE DETECTOR	ACS-7-6 DUCT ALARM		
081403	AREA SMOKE DETECTOR	ACS-7-1 AREA ALARM	POX-19-012	ACS-7-1
081404	DUCT SMOKE DETECTOR	ACS-7-1 DUCT ALARM		
081405	AREA SMOKE DETECTOR	ACS-7-14 AREA ALARM	POX-22-043	ACS-7-14
081406	DUCT SMOKE DETECTOR	ACS-7-14 DUCT ALARM		
081407	DUCT SMOKE DETECTOR	ACR-7-3 DUCT ALARM	GROUP B	GROUP B
081408	DUCT SMOKE DETECTOR	ACR-7-4 DUCT ALARM		
081410	DUCT SMOKE DETECTOR	ACR-7-13 DUCT ALARM	POX-27-091	ACR-7-13
081411	DUCT SMOKE DETECTOR		POX-22-043	ACS-7-14
081412	AREA SMOKE DETECTOR	E-7-19 DUCT ALARM	POX-29-113	E-7-19
081413	DUCT SMOKE DETECTOR	E-7-17 DUCT ALARM	POX-29-111	E-7-17
081414	AREA SMOKE DETECTOR	SMOKE IN TEL CLOS 9 NW		
		GROUP B POX-24-061 POX-24-062 POX-24-063 POX-24-064 POX-19-012 POX-20-021 POX-20-022 POX-20-023 POX-21-032	ACR-7-1 SHUTDOWN ACR-7-2 ACR-7-3 ACR-7-4 ACS-7-1 ACS-7-4 ACS-7-5 ACS-7-6 ACS-7-9	
081301	TAMPER SWITCH	TAMPER SWITCH 7 MER TWR 2	N/A	N/A
081302	WATER FLOW SWITCH	WATER FLOW 7 MER	N/A	N/A
081303	PURGE SWITCH 7 NE	BY-PASS ACTIVATED 7NE	N/A	N/A
081304	PURGE SWITCH 7 NW	BY-PASS ACTIVATED 7NW	N/A	N/A
081305	PURGE SWITCH 7 SE	BY-PASS ACTIVATED 7SE	N/A	N/A
081306	PURGE SWITCH 7 SW	BY-PASS ACTIVATED 7SW	N/A	N/A

SMOKE DETECTION PANEL XL No.8 SCHEDULE 'B'

INPUT		INITIATING DEVICES	RESULTING ADDRESS	ANNUNCIATOR MESSAGES	A
ADDRESS No. 1	ADDRESS No. 2				
081102	081103	POX-31-132 INTERFACE MODULE TRX-2R-8-9	081129		S P
081102	081104				
081105	081106	POX-31-131 INTERFACE MODULE TRX-2R-8-7	081130	SOL VALVE DUMP 7 EAST TWR 2	S G S G S G S G
081107	081108				
081201	081202				
081203	081204				
081205	081206				
081205	081207				
081208	081209	POX-31-133 INTERFACE MODULE TRX-2R-8-10	081128		S P
081301	081302	POX-31-134 INTERFACE MODULE TRX-2R-8-11	081229		S P
081303	081304	POX-31-131 INTERFACE MODULE TRX-2R-8-8	081230	SOL VALVE DUMP 7 WEST TWR 2	S G S G S G S G
081305	081306				
081307	081308				
081401	081402				
081403	081404	POX-32-141 INTERFACE MODULE TRX-2R-8-12	081228		S P S P S P S P
081405	081406				
081405	081107				
081405	081408				
				GROUP D	P C P C P C P C P C